

# Acceleration sensor ACY04-F99-2I-V15

- E1-Type approval
- Analog output 4 mA ... 20 mA
- Fixed evaluation limits
- High shock resistance
- Teachable zero point
- Measuring range -2  $g \dots$  +2 g
- Increased noise immunity 100 V/m

#### 2 axis acceleration sensor










## **Dimensions**




## Technical Data

Release date: 2020-04-24 Date of issue: 2020-04-24 Filename: 227702\_eng.pdf

| General specifications               |                            |  |  |
|--------------------------------------|----------------------------|--|--|
| Туре                                 | 2 axis acceleration sensor |  |  |
| Measurement range                    | -2 2 g                     |  |  |
| Resolution                           | ≤5 mg                      |  |  |
| Repeat accuracy                      | ≤±5 mg                     |  |  |
| Frequency range                      | 0 100 Hz                   |  |  |
| Functional safety related parameters |                            |  |  |
| MTTF <sub>d</sub>                    | 304 a                      |  |  |
| Mission Time (T <sub>M</sub> )       | 20 a                       |  |  |

| Technical Data                           |                |  |
|--|----------------|--|
| Diagnostic Coverage (DC)                 |                | 0 %  |
| Indicators/operating means               |                |  |
| Operation indicator                      |                | LED, green   |
| Teach-In indicator                       |                | LED, yellow  |
| Electrical specifications                |                |  |
| Operating voltage                        | $U_{B}$        | 10 30 V DC   |
| No-load supply current                   | I <sub>0</sub> | ≤ 25 mA  |
| Time delay before availability           | t <sub>v</sub> | ≤ 100 ms   |
| Analog output                            |                |  |
| Output type                              |                | 2 current outputs 4 20 mA (one output for each axis)   |
| Zero signal                              |                | 12 mA  |
| Slope of output characteristic           |                | 4 mA / g   |
| Linearity error                          |                | ± 1.2 %  |
| Load resistor                            |                | $0 \dots 200 \Omega$ at $U_B = 10 \dots 18 V$<br>$0 \dots 500 \Omega$ at $U_B = 18 \dots 30 V$ |
| Temperature influence                    |                |  |
| Offset                                   |                | $\leq$ ± 4 $\mu$ A / K   |
| Slope                                    |                | $\leq$ ± 20 $\mu$ A / $g$  |
| Compliance with standards and directives |                |  |
| Standard conformity                      |                |  |
| Shock and impact resistance              |                | 100 g according to DIN EN 60068-2-27   |
| Standards                                |                | EN 60947-5-2:2007<br>IEC 60947-5-2:2007  |
| Approvals and certificates               |                |  |
| UL approval                              |                | cULus Listed, Class 2 Power Source   |
| CCC approval                             |                | CCC approval / marking not required for products rated ≤36 V                                   |
| E1 Type approval                         |                | 10R-04   |
| Ambient conditions                       |                |  |
| Ambient temperature                      |                | -40 85 °C (-40 185 °F)   |
| Storage temperature                      |                | -40 85 °C (-40 185 °F)   |
| Mechanical specifications                |                |  |
| Connection type                          |                | 5-pin, M12 x 1 connector   |
| Housing material                         |                | PA   |
| Degree of protection                     |                | IP68 / IP69K   |
| Mass                                     |                | 240 g  |
|  |                |  |

## Connection



Acceleration sensor ACY04-F99-2I-V15

## **Connection Assignment**




Wire colors in accordance with EN 60947-5-2

| 1 | BN | (brown) |
|---|----|---------|
| 2 | WH | (white) |
| 3 | BU | (blue)  |
| 4 | BK | (black) |
| 5 | GY | (gray)  |

## **Characteristic Curve**

#### Frequency response



## **Accessories**



V15-G-2M-PUR

Female cordset, M12, 5-pin, PUR cable

#### Mounting

#### Installation orientation

On delivery, the zero position of the sensor axes is achieved when the sensor is mounted flat on a horizontal plane and the electrical connection of the sensor points horizontally sidewards.

### **Additional Information**

#### **LED display**

| Displays dependent on the operating state                 | LED     | LED         | LED yellow 2 |
|---|---------|-------------|--------------|
|   | green:  | yellow 1    |              |
|   | Power   |             |              |
| Normal operation  | on      | off         | off          |
| Teach In of reference point                               |         |             |              |
| Teach In (Pin 5 connected to +U <sub>B</sub> ) for 1 s 10 | on      | on          | off          |
| s   | on      | flashes 3 x | off          |
| falling slope at Teach In input                           | on      | off         | off          |
| then sensor returns to normal operation.                  |         |             |              |
| Reset to factory settings:                                |         |             |              |
| Teach In (Pin 5 connected to +U <sub>B</sub> ) for 20 s   | on      | on          | off          |
| 25 s  | on      | flashes 3 x | flashes 3 x  |
| falling slope at Teach In input                           | on      | off         | off          |
| then sensor returns to normal operation.                  |         |             |              |
| Undervoltage  | flashes | off         | off          |

#### **Factory settings**

see Technical Data

#### Teach-in of reference point (output S1)

- 1. Move sensor to reference position
- 2. Apply supply voltage (+Ub) to Teach In input (Pin 5) for 1 s ... 10 s
- 3. Teach In LED lights up for confirmation
- 4. Disconnect Teach In input (Pin 4) before the 10 s time elapses
- 5. Teach In LED flashes 3 x for confirmation
- 6. Reference point is now programmed and the sensor returns to normal operation (see LED display)

#### Resetting the sensor to factory settings

- 1. Apply supply voltage (+Ub) to Teach In input (Pin 5) for 20 s ... 25 s
- 2. Teach In LED lights up for confirmation
- 3. Disconnect Teach In input (Pin 4) before the 25 s time elapses
- 4. Teach In LED and Out LED flash 3 x for confirmation
- 5. The sensor is now reseted to factory settings and returns to normal operation (see LED display)

#### **Undervoltage detection**


If the supply voltage falls below a value of approx. 7 V, all outputs and yellow LEDs are deactivated. The green "power" LED flashes rapidly. If the supply voltage rises above a value of approx. 8 V, the sensor continues with normal operation.

### **Mounting**

#### Mounting of the sensor

Sensors from the -F99 series consist of a sensor module and accompanying cast aluminum housing. Select a horizontal flat surface with minimum dimensions of 70 mm x 50 mm to mount the sensor.

Mount the sensor as follows:







- Loosen the central screw under the sensor connection.
- 2. Slide back the clamping element until you are able to remove the sensor module from the housing.
- 3. Remove the sensor module from the housing
- 4. Position the housing at the required mounting location and secure using four countersunk screws. Make sure that the heads of the screws do not protrude.
- 5. Place the sensor module in the housing.



- 6. Slide the clamping element flush into the housing. Check that the sensor element is seated correctly.
- 7. Finally tighten the central screw.

The sensor is now mounted correctly.

## **Technical Features**

#### **EMC Properties**

Interference immunity in accordance with

DIN ISO 11452-2: 100 V/m

Frequency band 20 MHz up to 2 GHz

Mains-borne interference in accordance with ISO 7637-2:

| Pulse    | 1   | 2 | 2   | 3 | 3 | 4   |
|----------|-----|---|-----|---|---|-----|
|          |     | а | b   | а | b |     |
| Severity | - 1 | I | -1  | I | I | -1  |
| level    | - 1 | 1 | I   | 1 | 1 | - 1 |
|          | I   | ı | - 1 | ı | ı | - 1 |
| Failure  | С   | Α | С   | Α | Α | С   |

criterion

EN 61000-CD:8kV AD: 15 kV

4-2:

IV IV Severity

level

EN 61000-30 V/m (80...2500 MHz)

4-3:

Severity level

EN 61000-2 kV

4-4:

Severity Ш level

EN 61000-10 V (0.01...80 MHz)

4-6:

Severity

level

EN 55011: Klasse A